



For your nearest dealer call

1300 733 006

or visit Cost of Local Call.
Aust Only

www.mhpower.com.au

Contact Details

Australia:

VIC: (Head Office) Tel: 03 9763 0555 Fax: 03 9763 0577; **NSW:** Tel: 02 9674 3216 Fax: 02 9674 3299;
SA: Tel: 08 8340 2664 Fax: 08 8340 1482; **QLD:** Tel: 07 3394 8274 Fax: 07 3397 6115;
WA: Tel: 08 9245 1121 Fax: 08 92451510.

New Zealand:

Auckland: Tel: 09 415 6615 Fax: 09 415 8160; **Wellington:** Tel: 04 586 6188 Fax: 04 586 6088;
Christchurch: Tel: 03 358 8444 Fax: 03 358 8446



ULTIMATE™ Batteries...The toughest situations demand the ULTIMATE battery

**12 - Month Unlimited
Kilometre Conditional
Warranty**

ULTIMATE
AUTOMOTIVE AGM
DEEP CYCLE Maintenance-free
UL60 BCI Group: 8D
12V 60Ahcca 456CCArc 309CCA-sae RC88
9 plates 664CCArc & 62Ahc100

ULTIMATE
AUTOMOTIVE AGM
DEEP CYCLE Maintenance-free
UL60 BCI Group: 8D
12V 60Ahcca 456CCArc 309CCA-sae RC88
9 plates 664CCArc & 62Ahc100

12 month unlimited kilometre conditional warranty
Warranty void if used in under bonnet applications
Warranty void if labels are damaged or removed

These instructions form part of the warranty conditions:

- 12V (Regulated Lead acid (VRLA) Sealed Absorbed Glass Mat (AGM) battery
- Do not open or "top up" with water!
- Can be charged with Generator, Battery Charger or Solar
- Use only with alternators between 14.1V and 14.4V
- Use only an approved battery charger
- Use only with approved solar regulator
- Do not allow voltage to fall below 11.8V
- Do not leave flat - always recharge after use
- Do not short circuit terminals
- Battery is heavy - do not drop
- Approved for road use as per transport
- Do not install in upright compartment
- Will cause harm and fire for health less than 50A

DO NOT DISPOSE OF IN HOUSEHOLD WASTE OR RECYCLING BIN



ULTIMATE™

The ULTIMATE™ Battery range is suitable for:
4WDs • Caravans • Motorhomes • Marine
• Electric Outboards • And other deep cycle applications.

ULTIMATE™ Battery Range

All batteries come with a 12 - Month Unlimited Kilometre Conditional Warranty

Battery Model	Dimensions (mm) and Weight (kg)				Cold Cranking Amps			Volts	Thread Size (mm)	Reserve Capacity - Minutes Discharged					Capacity - Ampere Hour						
	Length	Width	Height	Weight	20°C (68°F)	0°C (32°F)	-18°C (0°F)			75 Amps	25 Amps	20 Amps	15 Amps	8 Amps	100 Hr	48 Hr	20 Hr	10 Hr	5 Hr	3 Hr	1 Hr
UL-60	229	138	213	18.6	597	466	309	12	6	20	88	123	172	360	62	59	54	50	44	41	34
UL-80	260	168	211	25.5	800	664	483	12	8	34	148	200	277	574	93	88	82	75	68	62	51
UL-100	306	168	211	29.6	861	751	546	12	8	46	178	236	332	689	113	106	98	90	80	74	61
UL-110	329	173	209	32.8	925	804	577	12	8	50	193	259	372	769	121	115	107	98	88	81	66
UL-120	409	177	225	36.4	963	877	683	12	8	63	231	295	424	886	141	133	123	113	100	92	76
UL-135	342	173	282	44.1	1048	951	800	12	8	86	283	377	532	1091	171	161	149	136	121	112	92
UL-160	530	209	214	54.2	1079	985	852	12	8	97	326	424	597	1230	189	177	164	150	133	123	101.5
UL-230	521	270	205	70.2	1173	1057	987	12	8	171	541	695	938	1998	289	271	251	230	204	189	155.4